


KB1-K 按鈕開關 Φ16




外觀 型式 形狀 型號 顏色 尺寸




		接點1C	接點2C
復歸 按鈕	○ 圓形	KB1-K211	KB1-K212
	□ 方形	KB1-K221	KB1-K222
	□ 矩形	KB1-K231	KB1-K232
保持 按鈕	○ 圓形	KB1-K311	KB1-K312
	□ 方形	KB1-K321	KB1-K322
	□ 矩形	KB1-K331	KB1-K332




大頭 復歸 按鈕	○ 圓形	KB1-K911	KB1-K912
	□ 方形	KB1-K921	KB1-K922
	□ 矩形	KB1-K931	KB1-K932
大頭 保持 按鈕	○ 圓形	KB1-K911H	KB1-K912H
	□ 方形	KB1-K921H	KB1-K922H
	□ 矩形	KB1-K931H	KB1-K932H



照光式		接點1C	接點2C
復歸 按鈕	○ 圓形	KB1-K271	KB1-K272
	□ 方形	KB1-K281	KB1-K282
	□ 矩形	KB1-K291	KB1-K292
保持 按鈕	○ 圓形	KB1-K371	KB1-K372
	□ 方形	KB1-K381	KB1-K382
	□ 矩形	KB1-K391	KB1-K392










大頭 復歸 按鈕	○ 圓形	KB1-K971	KB1-K972
	□ 方形	KB1-K981	KB1-K982
	□ 矩形	KB1-K991	KB1-K992
大頭 保持 按鈕	○ 圓形	KB1-K971H	KB1-K972H
	□ 方形	KB1-K981H	KB1-K982H
	□ 矩形	KB1-K991H	KB1-K992H



KB1-K 按鈕開關 Φ16




外觀	型式	形狀	型號	顏色	尺寸	
	二段 選擇 開關	☐ 圓形	KB1-K411	KB1-K412		
		☐ 方形	KB1-K421	KB1-K422		
		☐ 矩形	KB1-K431	KB1-K432		
		鑰匙 開關	☐ 圓形	KB1-K611		KB1-K612
			☐ 方形	KB1-K621		KB1-K622
			☐ 矩形	KB1-K631		KB1-K632
	三段 選擇 開關	☐ 圓形	KB1-K512			
			KB1-K522			
			KB1-K532			
		鑰匙 開關	☐ 圓形	KB1-K712		
			☐ 方形	KB1-K722		
			☐ 矩形	KB1-K732		
	緊急 按鈕	☐ 圓形	KB1-K811	KB1-K812		
	照光式 緊急 按鈕	☐ 圓形	KB1-K871	KB1-K872		
		指示燈	☐ 圓形	KB1-K170		
			☐ 方形	KB1-K180		
☐ 矩形			KB1-K190			
蜂鳴器		☐ 圓形	KB1-CZ10			
		☐ 矩形	KB1-CZ30			
LED 蜂鳴器		☐ 圓形	KB1-CZ10RL			
		☐ 矩形	KB1-CZ30RL			


KB1-F 按鈕開關 Φ16




外觀 型式 形狀 型號 顏色 尺寸




		接點1C	接點2C
復歸 按鈕	○ 圓形	KB1-F211	KB1-F212
	□ 方形	KB1-F221	KB1-F222
	□ 矩形	KB1-F231	KB1-F232
保持 按鈕	○ 圓形	KB1-F311	KB1-F312
	□ 方形	KB1-F321	KB1-F322
	□ 矩形	KB1-F331	KB1-F332




大頭 復歸 按鈕	○ 圓形	KB1-F911	KB1-F912
	□ 方形	KB1-F921	KB1-F922
	□ 矩形	KB1-F931	KB1-F932
大頭 保持 按鈕	○ 圓形	KB1-F911H	KB1-F912H
	□ 方形	KB1-F921H	KB1-F922H
	□ 矩形	KB1-F931H	KB1-F932H



照光式		接點1C	接點2C
復歸 按鈕	○ 圓形	KB1-F271	KB1-F272
	□ 方形	KB1-F281	KB1-F282
	□ 矩形	KB1-F291	KB1-F292
保持 按鈕	○ 圓形	KB1-F371	KB1-F372
	□ 方形	KB1-F381	KB1-F382
	□ 矩形	KB1-F391	KB1-F392







大頭 復歸 按鈕	○ 圓形	KB1-F971	KB1-F972
	□ 方形	KB1-F981	KB1-F982
	□ 矩形	KB1-F991	KB1-F992
大頭 保持 按鈕	○ 圓形	KB1-F971H	KB1-F972H
	□ 方形	KB1-F981H	KB1-F982H
	□ 矩形	KB1-F991H	KB1-F992H



KB1-F 按鈕開關 Φ16



外觀	型式	形狀	型號	顏色	尺寸		
  	二段		接點1C	接點2C			
	選擇 開關	○ 圓形	KB1-F411	KB1-F412		K	
		□ 方形	KB1-F421	KB1-F422			
		□ 矩形	KB1-F431	KB1-F432			
	鑰匙 開關	○ 圓形	KB1-F611	KB1-F612		K	
		□ 方形	KB1-F621	KB1-F622			
		□ 矩形	KB1-F631	KB1-F632			
	 	三段		接點1C	接點2C		
		選擇 開關	○ 圓形		KB1-F512		K
			□ 方形		KB1-F522		
			□ 矩形		KB1-F532		
		鑰匙 開關	○ 圓形		KB1-F712		K
□ 方形				KB1-F722			
□ 矩形				KB1-F732			
 		緊急 按鈕	○ 圓形	KB1-FA11	KB1-FA12		
			○ 圓形	KB1-F811	KB1-F812		
 		指示燈	○ 圓形	KB1-F170	W		
	□ 方形		KB1-F180	G			
	□ 矩形		KB1-F190	R			
				Y			
				B			